

# User Manual

## Power Manager PM1600



# Content

- Chapter 1 Introduction.....5**
- 1.1 Introduction of PM1600.....5
- 1.2 Caution.....5
  - 1.2.1 Danger.....5
  - 1.2.2 PRODUCT WARRANTY & CUSTOMER SUPPORT.....5
  - 1.2.3 LIMITATION OF WARRANTY.....5
  
- Chapter 2 Specifications.....6**
- 2.1 Main Features.....7
- 2.2 Hardware Specification.....8
- 2.3 Software Specification.....9
  
- Chapter 3 Installation and Wiring.....12**
- 3.1 Unpacking.....12
- 3.2 Installation.....12
  - 3.2.1 Panel Mount.....12
- 3.3 Wiring.....15
  - 3.3.1 Rear terminal.....15
  - 3.3.2 Digital output wiring.....16
  - 3.3.3 RS485 wiring.....16
  
- Chapter 4 Using the PM1600.....17**
- 4.1 Ways to operate PM1600.....17
  - 4.1.1 Operation through panel keys of PM1600 Host Machine.....17
  - 4.1.2 Operation through PM1600 Host Machine with USB mouse.....18
  - 4.1.3 Operating through Web Client.....18
- 4.2 General Operations.....20
- 4.3 Function Trees.....23
  - 4.3.1 Runtime Mode.....23
  - 4.3.2 Configuration Mode.....24
- 4.4 Connecting the PM1600 with client PC.....25
  - 4.4.1 Pier to pier connection.....25
  - 4.4.2 Network Connection.....25
- 4.5 Setting the PM1600.....30
  
- Chapter 5 Run Mode.....31**
- 5.1 System Overview.....31
- 5.2 Meter Group or Meter Display.....32
  - 5.2.1 Digital Display.....32
  - 5.2.2 Bar Chart Display.....33

5.3 Relay Status.....	34
5.4 Individual Meter Display.....	35
5.4.1 Digital Display.....	35
5.4.2 Summary Display.....	36
5.4.3 Real time Trend.....	38
5.4.4 Historical Trend.....	39
5.4.5 Graphical Display.....	40
5.5 Demand Control.....	43
5.5.1 Blocking mode.....	43
5.5.2 Rolling mode.....	44
5.6 Time of Use.....	45
5.7 Alarm/Event Log.....	46
5.8 Report.....	47
5.8.1 Aggregate Daily Report.....	47
5.8.2 Aggregate Monthly Report.....	48
5.8.3 Sub-Meter Daily Report.....	49
5.8.4 Sub-Meter Monthly Report.....	50
<b>Chapter 6 Configuration Mode.....</b>	<b>51</b>
6.1 System Setup.....	51
6.1.1 Date/Time Setup.....	52
6.1.2 Serial Communication Setup.....	53
6.1.3 Mailing List Setup.....	54
6.1.4 Mail Server Setup.....	57
6.1.5 TCP/IP Setup.....	59
6.1.6 Password Modification.....	61
6.1.7 User's Data Setup.....	61
6.2 Meter Setup.....	64
6.2.1 Basic Setup.....	65
6.2.2 Measure Setup.....	65
6.2.3 Alarm Setup.....	66
6.2.4 Trend Setup/ DATA Recording.....	68
6.3 TOU Setup.....	69
6.3.1 Season Setup.....	70
6.3.2 Day Type Setup.....	71
6.3.3 Holidays Setup.....	73
6.3.4 Rate Type Setup.....	73
6.3.5 Tariff Band Setup.....	77
6.4 Schedule Setup.....	79
6.4.1 Season Setup.....	80
6.4.2 Day Type Setup.....	81
6.4.3 Recurring Holidays Setup.....	82
6.4.4 Special Day Type Setup.....	83

6.4.5 Day Plan Setup.....	84
6.4.6 Day type Setup using Calendar.....	85
6.5 Demand Control Setup.....	87
6.5.1 Parameter Setup.....	88
6.5.2 Load Shed Setup.....	91
6.6 Group Setup.....	94
6.7 Data Backup.....	95
<b>Appendix.....</b>	<b>96</b>
Abbreviation.....	96

# Chapter 1 Introduction

## 1.1 Introduction of PM1600

PM1600 is designed for modern industrial sites, commercial facilities and utilities power management. By integration of power monitoring, demand control, power quality analysis, report generation and communication, PM1600 fulfills all daily power management requirements. Combines the state of art embedded system with information networking technologies, a high performance power supervisory control system can be built at a fairly low cost.

## 1.2 Caution



### 1.2.1 Danger

The PM1600 meter contains hazardous voltages. The meter should never be disassembled. Failure to observe this practice can result in serious injury or death. Any work on or near energized meters, meter sockets, or other metering equipment can present a danger of electrical shock. It is strongly recommended that all work should be performed only by qualified industrial electricians and metering specialist. Brainchild assumes no responsibility if your electrical installer does not follow the appropriate national and local electrical codes.

### 1.2.2 PRODUCT WARRANTY & CUSTOMER SUPPORT

Brainchild Electronic Co., Ltd. warrants all products free from defects in material and workmanship for a period of one year from the date of shipping in Taiwan.

Please have the serial number and a detailed problem description available when you report any defective. If the problem concerns a particular reading, please have all meter readings available. When returning any merchandise to Brainchild, an approval RMA number is required.

### 1.2.3 LIMITATION OF WARRANTY

This warranty does not apply to defects resulting from unauthorized modification, misuse, or use for reasons other than electrical power monitoring. The supplied meter is not a user-serviceable product.

## Chapter 2 Detail Specifications

<b>Power</b>	85~240VAC, 47~63Hz, 60VA, Maximum 23W
<b>Display</b>	6.4" TFT LCD, 640 x 480 pixel resolution, 24 bits colors
<b>Memory</b>	64 MB RAM , 32 MB Flash , 16 MB DOC , RTC(Battery back-upped)
<b>Interface</b>	USB: Host Port x1 Keypad: Function Key x7 , Arrow Key x4 LEDx2
<b>Digital Output</b>	Ports: 16 Contact Form: Normal on (N.O.) (form A) Relay Rating: 5A/240 VAC, life cycles 200,000 for resistive load
<b>COMM</b>	Interface: RS-485 x 1 Protocol: ModBus over serial line
<b>Standard Ethernet Communication</b>	Protocol: ModBus over TCP/IP Ports: Ethernet = 10/100Mbps Base T x 2
<b>Environmental &amp; Physical</b>	Operation Temperature: 5°C to 50°C Storage Temperature: -25°C to 60°C Humidity: 20 to 80%RH (non-condensing) Dimensions: 196mm (W) x 196mm (H) x 135mm (D) for panel mount
<b>Approval Standards</b>	Safety: Protective Class: EMC: Emission: EN61326 (EN55022 class A, EN61000-3-2, EN61000-3-3) Immunity: EN61326 (EN61000-4-2, EN61000-4-3, EN61000-4-4, EN61000-4-5, EN61000-4-6, EN61000-4-8, EN61000-4-11)

## **2.1 Main Features**

- Manage up to 16 units of power transducer
- Flexible field communication interfaces (Ethernet and RS485) for different power transducer connection
- Rich electricity parameters and power quality display for main and sub-feeder transducers
- Easy integrated with 3<sup>rd</sup> party supervisory control systems
- Remote power monitoring and control via intranet/internet
- Electricity demand control with 16 channel load shedding
- Multi-tariff management with TOU (Time-of-Use rate)
- Built in web server remote monitoring and control & data download
- Automatic report and alarm status sending by E-mail

## **2.2 Hardware Specification**

1. Power source : 85~240VAC, 47~63Hz, 60VA, max. 23W
2. Display : 6.4" TFT LCD, 640x480 pixels, 260,000 color
3. Memory : 64MB, 32MB Flash, 32MB Disc on chip (DOC)
4. Memory Storage Module :
  - (1) DOC : 32MB/64MB to store V,I,P...etc. 54 real time power data for over 1 year (up to DOC capacity option) , multi-tariff TOU report up to 3years and over 1024 alarm and event records.
  - (2) Support USB flash driver
5. Interface :
  - (1) USB Host Port x 1 : to connect mouse, key board or flash drive
  - (2) Key : 7function keys, 4 navigation keys.
6. Communication Module :
  - (1) RS485 x 1, communication protocol : Modbus RTU
  - (2) Ethernet interface ( 10/100Mbps Base T x 2 ), communication protocol : HTTP, SMTP
7. Outputs Interface :
  - (1) 16 digital control outputs ( no voltage, normal open, 5A/240V )
  - (2) Control Indicator x 1 ( Red LED ) : Alarm use
  - (3) power Indicator x 1

## 2.3 Software Specification

### 1. Power demand control :

- (1) Provide both blocking and rolling mode to calculate demand control.
- (2) Provide shedding modes with a combination of sequence and priority load shedding.
- (3) Real time display of :
  - (a) control capacity
  - (b) selected control mode
  - (c) current demand
  - (d) average demand
  - (e) demand control parameters
  - (f) status of demand control
  - (g) manual load shedding

### 2. Monitoring of power measurement :

- (1) display of real time values for each meters including : Voltage, current, power...etc. up to 54 real-time values.
- (2) digital or bar chart display for each real-time measurement data.

### 3. Monitoring of power quality : instant monitoring of harmonic distribution, THD, power factor and voltage variation for each channel.

### 4. Display of real-time and historic trend :

- (1) real-time trend display : to display trend of power information set by users.
- (2) historic display trend :
  - (a) to display historic trends of power consumption set by users.
  - (b) over a year of recorded data based on 15minuts data rate ( up to DOC capacity option ) .

### 5. Report inquiry

- (1) Main Meter :
  - (a) various power information at different tariff can be recorded separately.
  - (b) recorded information include : kWh, kvah, maximum demand, and happening time, average and standard deviation of phase voltage and max. and min. power factor with happening time.
  - (c) 300 days of daily report storage.

- (d) 24 months of monthly report storage.
- (2) Sub-meter :
  - (a) various power information at different tariff can be recorded separately.
  - (b) recorded information include : kWh, kvah, maximum demand, and happening time, average demand and load ratio.
  - (c) 300 days of daily report storage.
  - (d) 24 months of monthly report storage.
- 6. Alarm and event record
  - (1) Up to 29 different type of alarm ( such as : over voltage, over demand, phase imbalance, THD...etc. ) .
  - (2) On-off and time duration of each DO and system power.
  - (3) Up to 1024 alarm on event record.
  - (4) Auto email to decimated person while alarm table place.
- 7. Schedule control : devices can be controlled according to the pre-set season, date and hours.
- 8. System setup
  - (1) Communication setup.
  - (2) Network setup.
  - (3) Email setup.
  - (4) System time and screen protection time set up.
- 9. Meter setup
  - (1) Setup of meter address and tag name.
  - (2) TCP/IP ratio setup.
  - (3) Wiring setup.
  - (4) Table setup for recording information.
- 10. Setup for multiple tariff TOU management
  - (1) Start and end date setup for each season.
  - (2) Date type setup.
  - (3) Setup for recurring and non-recurring holidays.
  - (4) Start and end time for rate type setup ( peak, non-peak rate ) .
- 11. Demand control setup
  - (1) according to the rate type of TOU to set up :
    - (a) Contracted demand capacity.
    - (b) Target demand.

- (c) Alarm limit.
- (d) Load shedding limit.
- (2) Setup of demand control parameters :
  - (a) calculation algorithm.
  - (b) time interval of calculation.
  - (c) load shedding mode ( sequence or priority mode ) .
- (3) determine of load shedding mode and their involved control DO.

#### 12. Schedule control setup

- (1) Start and end time setup for each season.
- (2) Date type setup.
- (3) Setup for recurring holidays.
- (4) calendar setup.
- (5) Setup on/off time for each designated DO.

13. Information backup : historic date, reports, alarm and event records all can be back upped through USB flash drive.

#### 14. Remote monitoring and setup

- (1) Through web browser, real time values of each meter can be monitored and modified remotely (No additional software is required) .
- (2) Through web browser, system parameters can be configured.
- (3) Through web browser, historic data, reports, alarm and event records can be downloaded and saves.

# Chapter 3 Installation and Wiring

## 3.1 Unpacking

If any damage been is found while unpacking, the user should contact the local representative at once. It is suggested that the special packaging is suggested to retain for possible future requirement.

## 3.2 Installation

 Remove stains from this equipment using a soft, dry cloth. Don't use harsh chemicals, volatile solvent such as thinner or strong detergents to clean the equipment in order to avoid deformation.


The PM1600 is designed for indoor use and not in any hazardous area. It should be kept away from shock, vibration, and electromagnetic fields like such as variable frequency drives, motors and transformers.

It is intended to be operated in the following environment:


Pollution Degree Level II	IEC1010-1( EN61010-1 )
Temperature	5 ~ 50 °C
Humidity	20 ~ 80 % RH (non-condensing)
Power	90 ~ 240 VAC, 50/60 Hz

### 3.2.1 Panel Mount


#### ◆ The front side




### The left side



### ◆ Panel Cutout






### 3.3 Wiring

#### Wiring Precautions

1. Care must be taken to ensure that maximum voltage rating specified on the label is not exceeded.
2. It is recommended that near the equipment an external fuse and an external switch rated at 2A/250 VAC should be equipped.
3. Beware not to over tighten the terminals screws. The torque should not exceed 0.7 N-m ( 6.3 Lb-in or 7.1 Kg F-cm ).
4. Connect a grounding conductor with 1.6mm diameter minimum to provide protective grounding prior to turning on the equipment.


#### 3.3.1 Rear terminal




LAN1: To connect with Transducers over Ethernet network

LAN2: To connect with PC for web server function

**3.3.2 Digital output wiring**



**3.3.3 RS485 wiring**




# Chapter 4 Using the PM1600

In this chapter, focus will be given on things that you should understand before you actually start setting PM1600, including method of entering data, procedure, function trees.

## 4.1 Ways to operate PM1600

### 4.1.1 Operation through panel keys of PM1600 Host Machine

Press the function keys on the front panel to operate the PM1600.



Key	Function
◀ Page	Select a different data page to view
Page ▶	
▼ Meter/Grp	Change the target Meter or Meter-Group
Meter/Grp ▲	
Run/Config	Switch between Runtime and Configuration mode
Four-way navigation pad	Four-way navigation in Data Area

If entering numbers or letters are required, the screen will pop-up a screen keyboard. Simply use navigation keys and enter key to complete the filling.


#### **4.1.2 Operation through PM1600 Host Machine with USB mouse**

Using USB mouse to operate PM1600, simply move the cursor to the desire item and click the button to access, like using the mouse of PC. You can use the hard key mixed with soft button by mouse at the same time which make you operate the PM1600 in the field conveniently.

#### **4.1.3 Operating through Web Client**

Run the web manager program, and clicking its software function buttons, by using the cursor directly on the selected item and click.

## PMS Web Manager




Button	Function
<b>&lt;- Page</b>	Select a different data page to view
<b>Page -&gt;</b>	
<b>MVGrp -</b>	Change the target Meter or Meter-Group
<b>MVGrp +</b>	
<b>Chng Mode</b>	Switch between Runtime and Configuration mode
<b>Back</b>	Back to the parent data page

In order to use PC as a web client to access PM1600, TCP/IP setting must be completed first. Please see page 48, TCP/IP setting. (chapter 6.1.5)


## 4.2 General Operations

- **Change the operation mode between Runtime and Configuration**



Press the **Mode** key  to switch between the **Runtime** mode and the **Configuration** mode.


- **Menu navigation**




Select the desired function and press the **Enter** key  to perform

Press the **Esc** key  to back to the parent menu.

● **Textual fields with screen keyboard**



1. Use the **Arrow** key  to locate the desired textual field and press the **Enter** key  to begin editing.




2. While the **screen keyboard** appears, use the **Arrow** key  to move the mouse cursor, hover it above the letter you want, then press the **Enter** key  to type it.




3. To finish typing, type the **enter** key on the **screen keyboard**, or press the **Esc** key  to abort.

● **Selectable drop-down boxes**



1. Use the **Arrow** key  to locate the desired combo box and press the **Enter** key  to begin editing.



2. Press the up/down **Arrow** key  to scroll the drop down box and press the **Enter** key  to choose a value.

Or press the **Esc** key  to abort.

## ● Toggled check boxes

The screenshots show the 'Alarm Setup' screen with the following data:

Alarm Type	Setpoint	D/Zn(%)	En/Dis	E-Mailed
VIICA Over Voltage	0.00	0.00	<input type="checkbox"/>	<input type="checkbox"/>
VIIB Under Voltage	0.00	0.00	<input type="checkbox"/>	<input type="checkbox"/>
VIIBC Under Voltage	0.00	0.00	<input type="checkbox"/>	<input type="checkbox"/>
VIICA Under Voltage	0.00	0.00	<input type="checkbox"/>	<input type="checkbox"/>
Leading KVARH	200.00	2.00	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Polarity	0.00	0.00	<input type="checkbox"/>	<input type="checkbox"/>

1. Use the **Arrow** key to locate the desired check box.

2. Press the **Enter** key to toggle select the check box.

## ● Time picker fields

1. Use the **Arrow** key to locate the time picker field and press the **Enter** key to begin editing.

2. While the **calendar** box appears, use the **Arrow** key to move the mouse cursor, hover it above the date you want, then press the **Enter** key to select.

Or press the **Esc** key to abort.

The screenshots show the 'Daily Report' screen with the following data for 10/16/2005:


Rate Type	Off peak	From(h:mm)	To(h:mm)
Rate Type:Off peak	\$0.75	0:00	7:29
VMax(V)	A: 0.00(0:00)	B: 0.00(0:00)	C: 0.00(0:00)
VMin(V)	A: 0.00(0:00)	B: 0.00(0:00)	C: 0.00(0:00)
VAvg(V)	A: 0.00(+0.00)	B: 0.00(+0.00)	C: 0.00(+0.00)
Active Energy(KWh)	0.00	Reactive Energy(KVARH)	0.00
Peak Load(W)	0.00(0:00)	Avg Load(KW)	0.00
Power Factor	Max:0.00(0:00)	Min:0.00(0:00)	Load Ratio
Rate Type:On peak	\$1.98	7:30	22:29
VMax(V)	A: 117.46(18:53:57)	B: 117.58(18:53:46)	C: 117.53(21:42:54)
VMin(V)	A: 110.51(12:46:25)	B: 110.72(12:45:56)	C: 110.56(12:43:32)
VAvg(V)	A: 114.89(+1.49)	B: 114.87(+1.50)	C: 114.95(+1.52)
Active Energy(KWh)	104.12	Reactive Energy(KVARH)	12.20
Peak Load(KW)	21.81(18:56:27)	Avg Load(KW)	9.99
Power Factor	Max:1.00(18:59:20)	Min:0.80(14:5:43)	Load Ratio: 0.44

### 4.3 Function Trees

PM1600 has Runtime and Configuration two kind of operation model, and provide Run/Config. key to switch it:


#### 4.3.1 Runtime Mode

Runtime mode displays the meter real-time reading, demand control, alarm, and event report.



### 4.3.2 Configuration Mode

Configuration mode is used to set-up the system parameters, metering parameters, TOU and demand control parameters.



## **4.4 Connecting the PM1600 with client PC**

For using client PC to configure PM1600 and to monitor the PM1600, connection between PM1600 and client PC has to be established first. Basically, the communication goes through TCP/IP. Two ways of connection are described in the following section.

### **4.4.1 Pier to pier connection**

1. Connect PM1600 with PC by a pier to pier Ethernet cable. (Cross over cable)
2. On PM1600 side using hard keys or USB mouse, change to configuration mode and setting TCP/IP as IP : 192.168.2.240, Mask : 255.255.255.0 (refer to TCP/IP setting in chapter 6)
3. On PC side, setting IP address to 192.168.2.245, Mask to 255.255.255.0, and leave gat way and DNS blank.
4. Setting trusted site for PM1600 by including 192.168.2.240 in the trusted site group. (start browser → Tools → Internet option → Security → Trusted site → site → Add then type in 192.168.2.240 → uncheck the “ require sever verification for all sites in this zone”) .

### **4.4.2 Network Connection**

In this section you will need assistance for MIS department or your internet system providers to set up the connection.

1. Connect PM1600 with PC using LAN Ethernet cable.
2. On PM1600 side, power on PM1600 and switch to configuration mode the default user's names is “admin” and password is “admin”. Obtain TCPIP address, Mask and gat way from MIS or system providers, enter those data to PM1600 (as described in chapter 6) . Leave DNS blank for future use.
3. On PC side, include the PM1600 address into your PC trusted site.

If you experience the difficulty of communication due to the block ActiveX controls, then you should change some default of ActiveX controls and plug-ins setting by :

1. Brower → tools → internet option → security → trusted sites → custom level → download signed ActiveX controls → enable.
2. Brower → tools → internet option → security → trusted sites → custom level → indulge and script ActiveX controls not marked as safe for scripting → prompt.


## How to run web server

First use Ping instruction at the DOS prompt and make sure that communication is established properly between PC and PM1600 unit.

Format: Ping IP address of PM1600

Ex: Ping 192.168.0.201

If the communication is proper, then it shows reply as follows..



```
C:\ Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\user>ping 192.168.0.201

Pinging 192.168.0.201 with 32 bytes of data:


Reply from 192.168.0.201: bytes=32 time<1ms TTL=128
Reply from 192.168.0.201: bytes=32 time=1ms TTL=128
Reply from 192.168.0.201: bytes=32 time=1ms TTL=128
Reply from 192.168.0.201: bytes=32 time=1ms TTL=128

Ping statistics for 192.168.0.201:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\Documents and Settings\user>_
```

If communication is not proper, then it will show the reply as follows..

In this case, you need to set TCP/IP settings in both PC and PM1600. Please note that you should use proper cable and it should be connected at the label shown as “LAN2” at the PM1600



```
C:\ Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.


C:\Documents and Settings\user>ping 192.168.0.201

Pinging 192.168.0.201 with 32 bytes of data:

Request timed out.
Request timed out.
Request timed out.
Request timed out.

Ping statistics for 192.168.0.201:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\user>_
```




In the browser, you need to enter the following

Format:


http://IP address of PM1600/ipmisapi.dll

Ex: Assume IP address of PM1600 is 192.168.0.201, then

<http://192.168.0.201/ipmisapi.dll>



Click on Yes, when prompted as above.



User name: admin

Password: admin


Now click on “OK”, please do not enter on the keyboard, use mouse and then click on OK. If every thing is proper, then u should able to see data updating in the PC as follows..

The screenshot shows the 'PMS Web Manager' interface in a web browser. The title bar reads 'PMS Web Manager - Windows Internet Explorer'. The address bar shows 'http://192.168.0.201/jpniscopl.dll'. The page title is 'PMS Web Manager'. The main content area displays 'System Overview' for the date '2007/4/4 16:57:05'. There are several data tables:

System Overview							2007/4/4 16:57:05	
Overview	Group	Display	Meter	Dead Chk	TCU	Alm/Event	Report	
<b>Meter-0</b>								
VinA	VinB	VinC	kWT	kVAHT	kVAT			
113.78V	113.83V	113.77V	6.33W	-18.82VAR	11.05VA			
IA	IB	IC	PFT	Freq.	kWhTotal			
0.03A	0.03A	0.03A	-0.53	60.00Hz	0.00KWh			
			kWT	kWhTotal				
Meter-1			329.25KW	153.43kWh	Meter-2		329.25KW	153.43kWh
Meter-3			329.25KW	153.43kWh				

At the bottom of the data area, there is a box: 'Start Accumulated Time: 2007/4/4 16:21:58'. The footer contains navigation buttons: '< Page', 'Page >', 'M/Stop', 'M/Start', 'Chng Mode', and 'Back'.

# 4.5 Setting the PM1600



# Chapter 5 Run Mode

This chapter describes the complete functions of PM1600. Please first refer to the function tree chart to get familiar with PM1600 systematically. This will help you to use the powerful PM1600 quickly and properly.

## 5.1 System Overview

System overview is the designated root page when PM1600 is powered. In this page, the detail real time data of the main meter will be shown on the top part as well the brief data of all sub meters. The main meter is the meter that is selected as the target meter demand control.

**1. Main meter**

VhA	VhB	VhC	kWt	kVAr	kVAr
11.30KV	11.22KV	11.48KV	311.51KW	165.72KVAR	353.83KVA
IhA	IhB	IhC	PFT	Freq	kWhNet
11.23A	10.42A	9.58A	0.89	61.30Hz	2.88kWh

**2. Sub meter**

	kWt	kWhNet		kWt	kWhNet
Meter-1	311.51KW	2.88kWh	Meter-2	311.51KW	2.88kWh
Meter-3	311.51KW	2.88kWh	Meter-4	311.51KW	2.88kWh
Meter-5	311.51KW	2.88kWh	Meter-6	311.51KW	2.88kWh
Meter-7	311.51KW	2.88kWh	Meter-8	311.51KW	2.88kWh
Meter-9	311.51KW	2.88kWh	JF	311.51KW	2.88kWh
Meter-11	311.51KW	2.88kWh	Meter-12	311.51KW	2.88kWh
Meter-13	311.51KW	2.88kWh	Meter-14	311.51KW	2.88kWh
Meter-15	311.51KW	2.88kWh			

Start Accumulated Time: 2006/12/18 7:12:37

- 1. Main Meter : Display detail real time power value of main meter.
- 2. Sub Meter : Display real time power and energy value of each sub meter.


## 5.2 Meter Group or Meter Display

According to the group configuration setting, real time power value of each group of meter is displayed here in digital form or bar chart.



### 5.2.1 Digital Display


Display for up to 4 meters as a group, including real time Voltage, Current, Power, Power Factor in digital form.



Use METER/GROUP key to switch to next or previous meter group.

## 5.2.2 Bar Chart Display

This page display real time Voltage, Current, Power, Power Factor in bar- charts from your each meter group.



1. Max/Min current : Display each power max. and min. current of this day value.
2. If the meter does not return max and min values, PM1600 will show 0.

## 5.3 Relay Status

This page shows the status of all the controllable relays. The status of relays can be controlled by the demand control, schedule control or manual control. You can use the check box to over right the status by checked the check box or use the manual button to change.

**3. Manual control**

**2. Schedule Trigger**

**4. Relay Status**

**1. Demand Trigger**

**5. Next Operation**

No.	Name	Demand	Sch.	Manual	Status	Next Off	Next On
1	Relay #0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		Off		12:00
2	Relay #1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On	11:16	
3	Relay #2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On	13:00	
4	Relay #3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		Off		17:00
5	Relay #4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On	12:00	
6	Relay #5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On		
7	Relay #6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On		
8	Relay #7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	On	On		
9	Relay #8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On		
10	Relay #9	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		Off		
11	Relay #10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Off	Off		
12	Relay #11	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Off	Off		
13	Relay #12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		Off		
14	Relay #13	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On		
15	Relay #14	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On		
16	Relay #15	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		On		


Reset      Apply

Runtime

1. The “checked” check box enables or disables the relay triggered by the demand controller.
2. The “checked” check box enables or disables the relay triggered by the scheduler.
3. Turn the relay on/off manually, so that both the demand trigger and the schedule trigger are disabled simultaneously.
4. Show the current relay output status.
5. Show the information about the next schedule plan adopted from the scheduler.

## 5.4 Individual Meter Display

According to how the meter was configured, each meter will display its real time and historical power value in digital and graphic form. (see chapter 6.2.4 Trend/Data Recording)



1. Trend Display

### 5.4.1 Digital Display


This section displays real time values of voltage, currents, power factor energy, THD for each meter. Some meters may show different data set depend on wiring mode of meter.

1. Meter Name




Push Meter TRANSD/GROUP button to switch to different meter.

## 5.4.2 Summary Display



Summary display graphically shows the real time power value for each meter. It also provides the summary information of energy and peak demand for various tariff band. This will also be seen in report section.

### ● Electricity Values



- **Demand & Energy**

2. Date / Month

3. Date/Month Navigation

1. Daily / Monthly

4. Demand Rate

Tariff	Active Energy	Reactive Energy
Off Peak	44.48 kWh	17.20 VARh
On Peak	-39.94 kWh	-15.20 VARh


Tariff	Time	Peak Demand
Off Peak	12/18/2006 7:30:00	153.43 kW
On Peak	12/18/2006 7:45:00	153.65 kW

1. Switch to daily or monthly data display.
2. Select date and month.
3. Based on current page, select different time zone accordingly.
4. Based on the TOU rate setting, show the total values of energy, and peak demand.

### 5.4.3 Real time Trend



PM1600 can display various power values including voltage, current, power factor...etc. alone the time for each meter. The displayed item for each meter is varied according to the setting in the configuration mode ( see chapter 6.2.4 ) . Auto scale is the default for trend display. User can modify Y-axis scale by using Y maximum and minimum button.




1. Measure type indicates all the display items for this meter.
2. Display area for real time data.
3. PM1600 will automatically assign the proper Y-scale if auto-scale button is clicked.
4. Two buttons are provided for users to adjust the Y-maximum of Y-axis.

### 5.4.4 Historical Trend




Similar to real time trend, PM1600 can display various power data for each meter. The display items are the same as real time trend which are pre determined in the configuration mode for each meter.



1. Meter type indicates all the display items for this meter.
2. Display area for historical trend.
4. Date selection button.
5. Time scale ( x-axis ) adjust button to increase or decrease the time span.
6. Y-scale auto scale button.
- 7.8. Y-axis adjust button to modify the maximum and or minimum.


### 5.4.5 Graphical Display



PM1600 provides three graphic displays for each meter phasor display, harmonic profile and bar chart. Some meter may not have phasor display or harmonic data because the wiring mode or meter itself does not measure harmonic profile.

- **Phasor**


Display each of meter, three phase by axis, and current value.



- **Harmonic Profile**



Display each of the meter three phase voltage and current by harmonic distribution graphic.




**1. Wait Status / Refresh**

**2. Save Profile**

**3. Clear Profile**

1. PM1600 will trace the latest harmonic reading every 30 seconds. Do not click the refresh button during reading while the button display “waiting for data”.
2. Save the harmonic data to the area assigned by users.
3. Clear the current display date.

- **Bar Chart Display**



This section shows Voltage, Current, Power, Power Factor, Voltage THD, Current THD in bar chart form for each meter similar to group display in previous section.

**1. Meter Name**



1. Push METER/GROUP buttons to switch to different meter.

## 5.5 Demand Control

In this section, PM1600 demonstrate the demand control with two calculation algorithm: blacking and rolling.

### 5.5.1 Blocking mode


When the blocking mode was selected, PM1600 will follow the demand parameters, such as target demand,... etc., to carry out demand control. All these parameters are pre-entered in the configuration mode.

The red line shows the shutdown limit curer which means the relays will be triggered to off status when ever the predict demand line exceed the shutdown limit line during 15 minutes window. In the mean time the high load alarm box will be turned to red.

As the end of predict demand line ( light blue color ) exceed the alarm limit, the alarm check box will turn from green to red.

PM1600 also allow the operator to change the I/O status in this page by selecting the relay and click the enter key. There are three choice : Manual off, Manual on and automatic by demand control. The small letter by each I/O shows “M” or “A” accordingly.


In I/O status, green color stands for “off status”, and red color stands for “on status”.



1. Show the set up value of demand control parameter and real time value of related demand.
2. Shutdown Limit: shedding demand value, and will start shedding upon over load, as show in red line.
3. Target Demand: target demand value, as show in green line.
4. Current Demand: current demand value, as show in yellow line.
5. Predict Demand: predict demand value, as show in blue line.
6. User set up the demand time interval. This will be used as the time axis range, to display the latest demand data.

### 5.5.2 Rolling mode

Using the 1 hours axis to show the rolling demand calculation mode for the demand change.



In this figure, the green line shows the target demand. The yellow line is current load. The red line stand for the shutdown line to triggered the IO to shed the demand and the high load alarm will be changed to red color, when ever the yellow line goes above.

When current load exceed the alarm limit, the alarm box will be turned to read. All the designated IO relays which will be controlled by demand are listed in IO status area. Red color means on status and green means off status. Since the IO relay will be controlled by demand automatically, a small “A” will display by the relay. PM1600 will allow users to change the relay status in this page, the small letter there will be signed as “M”.

## 5.6 Time of Use

1. Demand Rate

2. Rate Band

4. Target Rate Band

3. Current Rate Band

5. Rate Band Detail

The screenshot displays the 'Time of Use Display' window for the date 2006/12/10 at 10:13:46. The window has several tabs: Overview, Group, Relay, Meter, Demand Ctrl, TOU (selected), Alarm/Event, and Report. The main table shows the following data:

Rate Type	Duration	Active Electricity	Peak Demand
Nonsummer Off Peak	00:00 - 07:29	44.48 KWh	153.43 KW
Nonsummer On Peak	07:30 - 22:29	-16.21 KWh	153.65 KW
Nonsummer Off Peak	22:30 - 23:59	0.00 KWh	0.00 W

Below the table is the 'Band Detail' section for the selected 'Nonsummer On Peak' band:

- Average Load: -5.96 KW
- Peak Load: 153.65 KW
- Active Electricity: -16.21 KWh (44.66 KWh - 28.45 KWh on Meter)
- Reactive Electricity: -6.22 KVARh (17.27 KVARh - 11.05 KVARh on Meter)
- VinA avg: 11.23 KV
- VinB avg: 11.19 KV
- VinC avg: 11.20 KV
- VinA std: 159.42 V
- VinB std: 162.11 V
- VinC std: 161.99 V

1. This column shows rates type in one day.
2. This column shows time duration of each rate type.
3. The current rate band will be displayed with the light blue colored background and show all the detailed in the Band Detail Area.
- 4.5. Move the highlight to examine the band detail for different rate band.

## 5.7 Alarm/Event Log

The screenshot displays the 'Alarm/Event List' interface. At the top, there are tabs for 'Overview', 'Group', 'Relay', 'Meter', 'Demand Ctrl', 'TOU', 'Alarm/Event', and 'Report'. The 'Alarm/Event' tab is selected. Below the tabs is a table with the following columns: 'Ack', 'Name', 'Type', 'Source', 'Status', 'Issue Time', and 'Clear Time'. The table contains several rows of event data. Two rows are highlighted: one in red (indicating an active alarm) and one in green (indicating a cleared alarm). Below the table, there is an 'Ack' button with a checkmark icon, and a set of navigation buttons: 'First Page', 'Prev. Page', 'Next Page', and 'Last Page'. Red arrows point from the text labels to these elements.

**1. Alarm / Event**


Ack	Name	Type	Source	Status	Issue Time	Clear Time
	Power Off	Event	System	Cleared	12/18/2006 6:38:52	
<input type="checkbox"/>	Demand Overload	Alarm	Main Meter	Alarm	12/18/2006 6:27:23	
	DO Off	Event	Relay #6	Cleared	12/18/2006 6:27:24	
	DO On	Event	Relay #6	Cleared	12/18/2006 6:26:52	
	DO Off	Event	Relay #3	Cleared	12/18/2006 6:26:20	
	DO Off	Event	Relay #2	Cleared	12/18/2006 6:25:49	
	DO Off	Event	Relay #0	Cleared	12/18/2006 6:25:17	
	DO Off	Event	Relay #15	Cleared	12/18/2006 6:24:45	
	DO Off	Event	Relay #14	Cleared	12/18/2006 6:24:15	
	DO Off	Event	Relay #8	Cleared	12/18/2006 6:23:43	
	DO Off	Event	Relay #4	Cleared	12/18/2006 6:23:11	
	DO Off	Event	Relay #6	Cleared	12/18/2006 6:22:39	
	DO Off	Event	Relay #13	Cleared	12/18/2006 6:22:08	
<input type="checkbox"/>	Demand Overload	Alarm	Main Meter	Normal	12/18/2006 6:21:37	12/18/2006 6:26:52
	DO Off	Event	Relay #9	Cleared	12/18/2006 6:21:37	

**2. Acknowledgement**

**3. Page Navigation**

1. The red background will express after the Alarm occurred, and will turn to green color after the status back to normal.
2. Press the acknowledge button, to acknowledge of that page message of alarm/event.
3. Forward or backward, to bourse Alarm/Event message.

## 5.8 Report



PM1600 provide daily and monthly reports for main meter also for every submeter.

### 5.8.1 Aggregate Daily Report

1. Date

2. Date Navigation

3. Rate Band

The screenshot shows the 'Aggregate Daily Report' interface. The title bar indicates the date '2006/12/18 10:14:58'. Below the title bar, there are four tabs: 'Aggregate Daily', 'Aggregate Monthly', 'Daily Summary', and 'Monthly Summary'. The 'Aggregate Daily' tab is selected. Below the tabs, there is a 'Date' field set to '2005/12/18' and a 'Workday' checkbox. To the right of the date field are four navigation buttons: 'First Page', 'Prev. Page', 'Next Page', and 'Last Page'. Below the navigation buttons is a table with two sections: 'Rate Type: Off Peak' and 'Rate Type: On Peak'. Each section contains several rows of data, including 'VMax(KV)', 'VMin(KV)', 'VAvg(KV(±V))', 'Active Energy(KWh)', 'Peak Load(KW)', and 'Power Factor'. The 'Off Peak' section has a light blue background, and the 'On Peak' section has a light yellow background. The 'Date' field and the navigation buttons are highlighted with red boxes and labeled '1. Date' and '2. Date Navigation' respectively. The 'Rate Type: Off Peak' label is highlighted with a red box and labeled '3. Rate Band'.

Rate Type: Off Peak	Rate	From(hh:mm)	To(hh:mm)
Rate Type: Off Peak	\$1.98	0:0	7:29
VMax(KV)	A: 11.51(7:14:45)	B: 11.43(7:14:17)	B: 11.48(7:26:53)
VMin(KV)	A: 10.97(7:27:39)	B: 10.92(7:15:41)	C: 10.93(7:15:4)
VAvg(KV(±V))	A: 11.22(±161.04)	B: 11.19(±161.52)	C: 11.28(±160.02)
Active Energy(KWh):	44.48	React. Energy(KVARh):	17.20
Peak Load(KW)	153.43(7:30:0)	Avg Load(KW):	153.10
Power Factor:	Max:0.99(7:15:58)	Min:0.87(7:25:21)	Load Ratio: 99.79%
Rate Type: On Peak	Rate	From(hh:mm)	To(hh:mm)
Rate Type: On Peak	\$2.80	7:30	22:29
VMax(KV)	A: 11.51(7:53:45)	B: 11.48(7:34:52)	B: 11.48(7:38:53)
VMin(KV)	A: 10.96(7:38:42)	B: 10.92(7:46:41)	C: 10.93(7:46:4)
VAvg(KV(±V))	A: 11.23(±159.88)	B: 11.19(±162.86)	C: 11.28(±162.06)
Active Energy(KWh):	-11.54	React. Energy(KVARh):	-4.59
Peak Load(KW)	153.65(7:45:0)	Avg Load(KW):	-4.20
Power Factor:	Max:0.99(7:50:58)	Min:0.87(7:31:21)	Load Ratio: -2.73%

1. Select the desired date.
2. Move to previous or next date.
3. Display detail power information for various rate bands separated by various color background. Please note that the time is displayed as “hh : mm : ss”.

## 5.8.2 Aggregate Monthly Report

1. Month

2. Month Navigation

3. Rate Band

Aggregate Monthly Report			
Aggregate Daily		Aggregate Monthly	
Date: 2009/12		Nonsummer	
Rate Type::Off Peak		\$1.98	
VMmax(KV)	A: 11.51(18 07:14:45)	B: 11.43(18 07:14:17)	C: 11.48(18 07:28:53)
VMmin(KV)	A: 10.97(18 07:27:39)	B: 10.92(18 07:15:41)	C: 10.93(18 07:15:04)
VAvg(KV(±V))	A: 11.22(±161.84)	B: 11.19(±161.52)	C: 11.20(±168.82)
Active Energy(KWh):	44.48	React. Energy(KVARh):	17.20
Peak Load(KW)	153.43(18 07:30:08)	Avg Load(KW):	153.10
Power Factor:	Max:0.99(18 07:15:58)	Min:0.87(18 07:25:21)	Load Ratio: 99.79%
Rate Type::On Peak		\$2.00	
VMmax(KV)	A: 11.51(18 07:53:45)	B: 11.48(18 07:34:52)	C: 11.48(18 07:38:53)
VMmin(KV)	A: 10.96(18 07:38:42)	B: 10.92(18 07:46:41)	C: 10.93(18 07:46:04)
VAvg(KV(±V))	A: 11.23(±168.47)	B: 11.19(±161.77)	C: 11.20(±161.32)
Active Energy(KWh):	-36.70	React. Energy(KVARh):	-14.13
Peak Load(KW)	153.65(18 07:45:08)	Avg Load(KW):	-9.99
Power Factor:	Max:0.99(18 07:50:58)	Min:0.87(18 07:31:21)	Load Ratio: -6.50%

1. Select the desired month.
2. Month navigation.
3. Display detail information for various rate bands separated by different color background. Please note that the time is displayed as “dd : mm ss” slightly different from daily report.

### 5.8.3 Sub-Meter Daily Report

1. Meter      2. Date      3. Date Navigation

4. Meter Detail

Name	Active Energy	Reactive Energy	Average Load	Peak Load	Load Ratio
1 Main Meter	8.52 KWh	3.58 VARh	762.13 W	153.65 KW	0.50 %
2 Meter- 1	8.52 KWh	3.58 VARh	762.13 W	153.67 KW	0.50 %
3 Meter- 2	8.52 KWh	3.58 VARh	762.13 W	153.68 KW	0.50 %
4 Meter- 3	8.52 KWh	3.58 VARh	762.13 W	153.68 KW	0.50 %
5 Meter- 4	8.52 KWh	3.58 VARh	762.13 W	153.67 KW	0.50 %
6 Meter- 5	8.52 KWh	3.58 VARh	762.13 W	153.67 KW	0.50 %
7 Meter- 6	8.51 KWh	3.56 VARh	761.63 W	153.71 KW	0.50 %

ENERGY		
Tariff	Active Energy	Reactive Energy
Off peak	53.17 kWh	20.16 VARh
On peak	0.00 kWh	0.00 VARh

DEMAND		
Tariff	Time	Peak Demand
Off peak	5/5/2006 2:26:04	329.25 kW
On peak	0/0/ 0 0:00:00	0.00 W

1. Display all sub meter daily data in a summary form.
2. Date selection.
3. Date navigation.
4. To examine any particular sub meter in detail, select the meter you like and click the meter detail button.

## 5.8.4 Sub-Meter Monthly Report

1. Meter

2. Month

3. Month Navigation

	Name	Active Energy	Reactive Energy	Average Load	Peak Load	Load Ratio
1	Main Meter	9.76 KWh	4.08 VARh	872.33 W	153.65 KW	0.57 %
2	Meter- 1	9.76 KWh	4.08 VARh	872.33 W	153.67 KW	0.57 %
3	Meter- 2	9.76 KWh	4.08 VARh	872.33 W	153.68 KW	0.57 %
4	Meter- 3	9.76 KWh	4.08 VARh	872.33 W	153.68 KW	0.57 %
5	Meter- 4	9.76 KWh	4.08 VARh	872.33 W	153.67 KW	0.57 %
6	Meter- 5	9.76 KWh	4.08 VARh	872.33 W	153.67 KW	0.57 %
7	Meter- 6	9.75 KWh	4.08 VARh	871.53 W	153.71 KW	0.57 %
8	Meter- 7	9.76 KWh	4.07 VARh	872.25 W	153.73 KW	0.57 %
9	Meter- 8	9.75 KWh	4.08 VARh	872.11 W	153.73 KW	0.57 %
10	Meter- 9	9.76 KWh	4.08 VARh	872.94 W	153.70 KW	0.57 %
11	JF	9.77 KWh	4.06 VARh	873.61 W	153.67 KW	0.57 %
12	Meter-11	9.77 KWh	4.06 VARh	873.61 W	153.67 KW	0.57 %
13	Meter-12	9.77 KWh	4.06 VARh	873.61 W	153.68 KW	0.57 %
14	Meter-13	9.77 KWh	4.06 VARh	873.61 W	153.68 KW	0.57 %
15	Meter-14	9.75 KWh	4.08 VARh	872.11 W	153.68 KW	0.57 %
16	Meter-15	9.75 KWh	4.08 VARh	872.06 W	153.69 KW	0.57 %

1. Display all sub meter monthly data in a summary form.
2. Month selection.
3. Month navigation.
4. To examine any particular sub meter in detail, select the meter you like and click the meter detail button.


## Chapter 6 Configuration Mode

In order to properly use PM1600 for different application and situation, PM1600 must be configured before use. The detail configuration tree was listed below. Again, please first refer to the function tree chart, to obtain a systematic idea.


There are seven functions can be set for PM1600, some are required, some are not. From part one, users can easily distinguish the required from non-required. The following will give a detail description for each function.

### 6.1 System Setup

System Setup is the first thing to begin with for setting the system that fulfills the user's requirement. It includes data/time setup, communication setup, mail list setup, mail server setup, TCPICP setup, password modification and user's data setup.




1. Use the **Arrow** key  to navigate among the functions, then press the **Enter** key  to perform.



2. Press the **Page** key == to switch from the neighbor function.

### 6.1.1 Date/Time Setup


It is important to set the correct data and time for PM1600, because it involves the schedule control, rate type and also demand control. After entering all the correct data, click the apply key to finish the change.



1. Press the **Enter** key  to begin adjusting, or press the **Esc** key  to exit this dialog.
2. Adjust the system time or the screen off time.
- 3a. Finally, select the **Apply** button and press the **Enter** key  to apply the new value.
- 3b. Or select the Cancel button and press the **Enter** key  to drop all the changes.

### 6.1.2 Serial Communication Setup

In order to obtaining data from each meter, PM1600 must be entered the needed information for each meter. PM1600 requires baud rate, data bits, stop bits and priority from each meter. The above data should be provided by meter manufacturer. After entering the proper values, click the apply key. If the data enter is incorrect, PM1600 will show communication fail in the runtime mode.




1. Use the **Arrow** key  to navigate among the fields. Press the **Enter** key  to begin editing.
2. Press the **Arrow** key  to scroll the drop down box and press the **Enter** key  to choose the value.
3. Select the **Apply** button to apply the new value or the **Cancel** button to drop the change, then press the **Enter** key .

### 6.1.3 Mailing List Setup


In this section, PM1600 need to know where to send the alarm report and regular report. Use the set button in the bottom left of the screen to move around alarm or report mailing list. If edit, add, delete is required, use the respective button to make the necessary change. Again apply button has to be click to enter the data.

- **Change the target mailing list**




1. Use the **left/right Arrow** key  to select the **Set** button and press the **Enter** key  to toggle between the **Alarm mail list** and the **Report mail list**.

● **Add a new E-Mail address**




1. Use the **Arrow** key  $\leftarrow$  to select the **Add** button and press the **Enter** key  $\rightarrow$  to begin to add.
2. Select the **Apply** button and press the **Enter** key  $\rightarrow$  to apply the new value.

● **Modify an E-Mail address**



1. Use the **up/down Arrow** key  $\updownarrow$  to highlight the desired E-Mail address.
2. Use the **left/right Arrow** key  $\leftarrow \rightarrow$  to select the **Edit** button and press the **Enter** key  $\rightarrow$  to begin to modify.
3. Use the **screen keyboard** to edit both the name field and the address field.
4. Select the **Apply** button and press the **Enter** key  $\rightarrow$  to apply the new value.


- **Delete an E-Mail address**



1. Use the **up/down Arrow** key  $\updownarrow$  to highlight the desired E-Mail address.
2. Use the **left/right Arrow** key  $\leftarrow$  to select the **Delete** button and press the **Enter** key  $\rightarrow$  to begin to modify.
3. Select the **Apply** button and press the **Enter** key  $\rightarrow$  to apply the deletion.

### 6.1.4 Mail Server Setup

Each PM1600 connected to Ethernet has its own identity as sender address and login name. Therefore, the receivers will know where these reports are from. Obtain the server address and server port from your internet system provider (ISP) or MIS manager. Assign this PM1600 with unique sender address, login name, and password to precede the mailing.



1. Use the **up/down Arrow** key  to navigate among the fields.
2. Use the **left/right Arrow** key  to select the **Edit** button and press the **Enter** key  to begin to edit.
3. Type the **screen keyboard** to fill out the field.
4. Select the **Apply** button and press the **Enter** key  to apply the change.
5. Select the **Test** button to test the **SMTP mail server**. If succeed, you will get a successful message, otherwise a failed message will be shown.
6. If succeed, you will get a successful message, or a failed message will be shown.

### **6.1.5 TCP/IP Setup**


If PM1600 is connected with PC directly using Ethernet cable, private IP is used for both PM1600 and client PC. In this case, PM1600 does not have email function since it is not network connected. For example: IP can be assigned as 192.168.n.h., where n is network ID, PM1600 and client's PC use same number, and h is host ID which PM1600 and client PC use different number.

If wide area network was employed to connect PM1600 and PC client, two options of IP address are shown in this page. Always consult with your IT department to select the option and the needed information such as IP address, subnet mask and default gateway. Please note that if DHCP is enabled as the selected option, it is possible that the client PC from remote area may not read PM1600 data since it uses floating IP address. However, the email function still can send the report.


DNS server section is reserved for future application. Please leave them blank.



1.



2.




3.

4.


1. Select this option to obtain an **IP address** from the DHCP server automatically.
2. Select this option to set the **IP address** manually using the **screen keyboard**.
3. The **DNS server** must be specified if you set the **IP address** manually, or it becomes optional.
4. Select the **Apply** button and press the **Enter** key  to apply the change.

### 6.1.6 Password Modification

This section allow current user to change his password by entering the password.



1.



2.


1. Input the new user name and the password.
2. Press the **Apply** button to apply all changes.

### 6.1.7 User's Data Setup

This section is used to manage the privilege to access the PM1600. Fore group levels of user are designed here as admin, eng. operator and guest. First of all, this current page can only be seen by admin group which is given the right to add or delete new users and assign their group levels. In engineer group level, he can use both runtime and configuration mode, so as to change the PM1600 setting in both mode. Operator level and can only do the change or modification within runtime mode. In guest level, all he can do is “look”.




For user's convenient and security, PM1600 in this page is allow users to set if the system will check operator or engineer ID or not. If check engineer box is clicked, then password will be asked every time the system switches to configuration mode. If check operator is triggered, them password will be asked when change any status in runtime mode.

● **Add a new account**



1. Press the **Add** button to start adding an account.
2. Select the authority level and in put the user data.
3. Press the **Apply** button to apply all changes.


- **Set up the security check**




1. Check the “Check Operator” to enable security check in the runtime mode.
2. Check the “Check Engineer” to enable security check while switching into the configuration mode.
3. Press the **Apply** button to apply all changes.

## 6.2 Meter Setup

In this section, users can setup every individual meter for their own properties. There are four setup have to completed.




1. Use the up/down **Arrow** key  to navigate among the functions, then press the **Enter** key  to perform.



1. Press the **Page** key  to switch from the neighbor function.

## 6.2.1 Basic Setup


In this section, PM1600 like to know every meter's ID like the Tag name, the location and the Model of the meter. To enter the right meter address, users have to set the address code in meter side or obtain the address code from meter's manufacturer and enter this number in this page.



1. Use the **screen** keyboard to fill out the two fields.
2. Select the **model** and press the **Enter** key  to choose.
3. Select the **Apply** button and press the **Enter** key  to apply the change.
4. For adding next meter, click Mt/Gkpt button.

## 6.2.2 Measure Setup


For correctly reading the right data, users have to specify the wiring method and values of primary PT&CT ratio and second PT&CT ratio. These information can be obtained from field engineers on system integrator.



1. Select the wiring mode and press the **Enter** key  $\bullet \leftarrow$  to choose.
2. Use the **screen keyboard** to fill out these fields.
3. 2. Select the **Apply** button and press the **Enter** key  $\bullet \leftarrow$  to apply the change.

### 6.2.3 Alarm Setup

PM1600 designs Sag, Swell, Voltage imbalance, current imbalance, lines over voltage...etc. for alarm, as shown in the window. These data for alarm from each meter are data provided by meter or defined by users, and PM1600 will perform the alarm function with comparison of set point setting. On the other hand if meter dose not provide data, then PM1600can not perform the alarm function. Users are asked to enter the set point and dead zoon, and checked the En/Dis (Enable and Disable) check box . Users can also decide to E-mailed the alarm data by clicking the check box of e-mailed.




1. Use the **screen keyboard** to fill out these fields.
2. Toggle the status of these check boxes by pressing the **Enter** key  $\bullet \leftarrow$
3. Select the **Prev/Next** button and press the **Enter** key  $\bullet \leftarrow$  to navigate among the alarm pages.
4. Select the **Apply** button and press the **Enter** key  $\bullet \leftarrow$  to apply the change.

## 6.2.4 Trend Setup/ DATA Recording

PM1600 allow users to select the measuring data to save for further display and analysis. User select the item listed in the left grid and click the add button to the right grid which display the item of data will be saved and displayed in the runtime mode.


Users can use the change grid button and move the highlight to the right grid to delete the item in the right grid. Up to 12 measurement can be saved and displayed.



1. Select the desired measure, then press the **Pick** button to choose.
2. Press the **Apply** button to start applying the changes.


## 6.3 TOU Setup

Tariff change as season, weak, day etc. In order to understand the expense of electricity at different time interval, TOU is designed to let the user to specify the various time type according to the local utility tariff policy.



1. Use the up/down **Arrow** key  to navigate among the functions, then press the **Enter** key  to perform.





Perform a function from the detailed dialog :



2. Press the **Page** key  to switch from the neighbor function.

### 6.3.1 Season Setup



PM1600 allow you to setup up to four seasons in one year. Users have to specify the start date for every season. Operations are described below.



1. Use the **screen keyboard** to type the **season names, and state date**, then press the **Enter** key  to choose. PM1600 will assign the day before state date of next season as the end date automatically.
2. The **Delete** function deletes the **last season**.
3. Select the **Save** button and press the **Enter** key  to apply the change.

### **6.3.2 Day Type Setup**


This section mainly to define the day type in one week, for examples: weekday and weekend. Users only need to specify the state date and PM1600 will provide end date as one day before next start date.



1. Use the **screen keyboard** to type the **day type**. Select the **end weekend** and press the **Enter** key  $\text{O}^{\text{ESC}} \leftarrow$  to choose.
2. The **Delete** function deletes the **last day type**.
3. Select the **Apply** button and press the **Enter** key  $\text{O}^{\text{ESC}} \leftarrow$  to apply the change.

### 6.3.3 Holidays Setup

In the section, holiday will be entered whether they are recurring every year like New Year Day or non-recurring day like Labor Day or Memorial Day. Users select recurring or non-recurring grid to enter the data first.




1. Select the **Add** button, then press the **Enter** key  to add a holiday.
2. Select the **Apply** button and press the **Enter** key  to apply the change.

### 6.3.4 Rate Type Setup


To calculate the expense of electricity, PM1600 allow users to enter different rate type, for instance: peak rate, non-peak rate, semi peak rate..., or rate1, rate2, etc. Detail operation is described below.

● **Add a new Rate Type**





1. Use the **four Arrow key**  to select the **Add** button and press the **Enter** key  to begin to add.
2. Use the **screen keyboard** to type the rate type name.

● **Modify a Rate Type**



1. Use the **up/down Arrow key**  to locate the **rate type**, then press the **Enter** key  to begin editing.
2. Use the **screen keyboard** to type the rate type name.

- **Delete a Rate Type**




1. The **Delete** function deletes the **last Rate Type**.
2. Select the **Apply** button and press the **Enter** key  to apply all the changes.

### 6.3.5 Tariff Band Setup

After setting season, day type, rate type, Tariff band can then be determined in this section. At each band, users have to specify season, day type, rate type, and start time complete the each band setting. For instance, summer, weekday, rate1 is from 00:00 to 07:00 as band1, rate3 is from 07:01 to 21:00 as band2 and rate1 is from 21:01 to 23:59 as band3.

To set weekend, just change weekday to weekend and set the band for that day again.



1. Define a **tariff band** by selecting the related **season, day type, rate type**.
2. Then select the **end time** for the **tariff band**.
3. If the setting is not finished, the default **end time** of the next **tariff band** will be provided automatically.
4. The **Delete** function deletes the last **tariff band**.
5. Select the **Save** button and press the **Enter** key  to apply the change.

If seasons, day type or rate type has been modified, PM1600 will ask users to redefine all the tariff band before leaving the configuration mode. Since these change will also affect the setting of demand control, users will also have to redo the setting in demand control section before leaving the configuration mode also.


# 6.4 Schedule Setup

In chapter 6.3 is mainly to setup the detail tariff bands for each day in every week and season for the whole year. It is used to calculate the electricity expanse. In this section, all the time zone are redefine to setup a day plan to control the relays. Therefore, PM1600 require you to enter the season setup, day type setup...etc. again for day plan to control relays which should differ from tariff bands in chapter 6.3. Again schedule setup is designed for turn on/off for the devices like a timer.



### 6.4.1 Season Setup


Users can define seasons according to its own application, such as: winter break, spring semester or summer energy saving season, etc. Users key in only the start date (mm/dd). One day before next season start day will be the end date of the previous season automatically.



1. Press the **Add** button to start adding a season type.
2. Input the season type name and select the start date.
3. Press the **Apply** button to apply all changes.

## 6.4.2 Day Type Setup


Like day type setup in TOU section, PM1600 provide up to 7 day types in a week for users to define. Like previous section, one day before the next day type will be assigned to be the end date of previous day type.



1. Press the **Add** button to start adding a day type.
2. Input the day type name and select the start date.
3. Press the **Apply** button to apply all changes.

### 6.4.3 Recurring Holidays Setup


All the recurring holiday is entered in this page.




1. Press the **Add** button to start adding a recurring holiday.
2. Select the month and day, then input the description.
3. Press the **Apply** button to apply all changes.

## 6.4.4 Special Day Type Setup


Besides recurring holiday, PM1600 is allowed to set special day type other than weekday, weekend according to user's application, for instance, the New Year eve day, long week end etc. The setting in this section is similar to previous section.



1. Press the **Add** button to start adding a special day type.



2. Input the name of the special day type.




3. Press the **Apply** button to apply all changes.

1. Press the **Add** button to start adding a special day type.
2. Input the name of the special day type.
3. Press the **Apply** button to apply all changes.

### 6.4.5 Day Plan Setup

After season, day types are determined, for every relay users should plan this particular on/off schedule. For example, chill relay will be off from 00:00 and on at 7:30, off 12:00, then turn on again at 2230. The user can set this relay accordingly. Those relays will be set for every season and every day type if schedule control is necessary.



1. Select the target **Season/Day Type/Relay** to edit.
2. Press the **Add** button to start adding a schedule.

3. Choose the trigger signal and the start time for each schedule.
4. Press the **Apply** button to apply all changes.

### 6.4.6 Day type Setup using Calendar

PM1600 provide the user a convenient way to setup day type directly through calendar. We suggest that users should use this function to setup those non-recurring special day types. The user can also use this function to change the original setting for one-time event. For example, change new year day from holiday to workday, when none is chosen, it means the scheduling is directed by previous day type setting.

1. Select the month and the year to change the monthly calendar, then locate the target date to schedule.



2. Choose the desired event for the schedule date.




3. Press the **Apply** button to apply all changes.



1. Select the month and the year to change the monthly calendar, then locate the target date to schedule.
2. Choose the desired event for the schedule date.
3. Press the **Apply** button to apply all changes.

# 6.5 Demand Control Setup

This section is one of the most important function of PM1600. Users are required to setup all the parameters for PM1600 to carry out the demand control accordingly.



### 6.5.1 Parameter Setup

PM1600 is designed for users to control demand according to various season and rate type due to different contract capacities. Users have to setup every season type and rate type to carry out demand control differently. Therefore, you have seasons and rate types combination to set this page.

To setup demand control, select one season type go through all the different rate types such as peak, off peak and semi peak.

Under every case, the rest of information in this page has to be entered. The rate column means electricity rate per kwh for that season and rate type. "Contract" column means contract capacity. Target column is the capacity that demand control will follow as the set point.


For alarm value, a percentage above the target value is required to enter here. For example 5%, then 5 is entered. Shutdown limit is the percentage off the target value that the PM1600 will start load shedding when the predicted demand value is above the upper bound of shutdown limit, or start load reinstall when the predicted demand value is lower then the lower bound of shutdown limit. In another word, away from the shutdown limit zone the PM1600 will execute load shedding or reinstall. If within the zone, the system will not automatically turn the relay on or off. Therefore the percentage of shutdown limit is critical in doing demand control, 10% is a good point to start with.

Target meter is the meter in which the reading of KW will be used to carry on the demand control as the target, which usually is the main meter of the system. PM1600 has two options to perform the demand control : blocking mode and rolling mode. The different of these two modes please refer to the reference ( or appendix ) . The demand time interval is depend on the local power company policy, usually is 15 minutes.

If blocking mode is selected, PM1600 will ask the time then it will start doing control. Here we suggest 3 min. The PM1600 won't do any control action until 3min. into blocking period.

If rolling mode is selected, subinterval no. will be entered to roll the period accordingly. If 3 is entered, then every 5 minutes (  $15/3=5$  ) the data will be replaced to calculate the demand.

The last item is shed mode which users will determine the priority of shedding. If sequence mode first is selected, PM1600 will do load shedding starting from the sequence first mode list, then followed by the priority first mode list. If priority first is selected here, PM1600 will do the load shedding starting from priority first list then sequence first list later. Please also note where sequence first mode is executed, the relay which on the top will be turned off first when it is necessary, and followed by the second, third...etc. As the load reinstalled start, the first relay, which is turned off, will be reinstalled first also. However, in the priority first mode the relay which is turned off first will be reinstalled lastly since it is the lowest priority for power usage.




1. Select the target seasonal demand rate to edit.
2. Set properties and limits of this target demand rate.
3. Choose a meter as the power usage feeder. Then determine the method to calculate the demand.
4. Specify the demand interval. If “Rolling” mode is adopted, the subinterval should also be assigned.

5. set restart time of the demand controller in each demand interval.
6. Specify the precedence between the sequential shedding and the priority shedding.
7. Press the **Apply** button to apply all changes.

### **6.5.2 Load Shed Setup**

In this section, load control will be carried out through turn the relay off and on. In this page, PM1600 will list all the available relays on the right hand side grid. Users will establish the priority of the relay that will be controlled accordingly by selecting the available relays and add to left side grid as the priority list. Users have two lists to complete, one for priority first and the other is sequence first. The different of these two lists are explained in previous section.


- **Enable a relay to shed load**




1. Select the target relay group to edit.
2. Choose the desired relay and press the **Add** button to join into the target relay group.
3. Press the **Modify** button to change the relay name and the amount of power.
4. Press the **Apply** button to apply all changes.

- **Adjust sequence of load shedding**

The priority list can also be adjusted when it is necessary, by the following steps.



1.




2.

1. Highlight the target relay and press the **Up/Down** button to change its sequence.
2. Press the **Apply** button to apply all changes.

## 6.6 Group Setup


Since PM1600 can connect up to 16 meters, users can group up to four meters as one group, and then the data will be shown together in the runtime mode. This function will allow users to compare data conveniently.



1. Select the desired **group** by pressing the **Device** key <ID/GMP> .
2. Use the **screen keyboard** to type the **group name**.
3. Select the desired **meters** for this **group**, then press the **Enter** key ⏎ to choose.
4. Select the **Apply** button and press the **Enter** key ⏎ to apply the change.

## 6.7 Data Backup

In this section, PM1600 allow users to backup the data in its memory to either PC or USB flash driver. If back up is carried out by web client, the data will be stored in PC. If back up is performed by host machine through USB, the data will be stored in USB flash driver.



1. Select the desired data to be backed up.
2. Insert an USB flash disk, then press the **Backup** button to start backing up.

## **Appendix**

### **A. Abbreviation**

TOU : Time of use

V. : Voltage

I. : Current

KW : Kilowatt

KWh : kilowatt-hour

Va : Voltage of phase A

Ia : Current of phase A

Vb : Voltage of phase B

Ib : Current of phase B

Vc : Voltage of phase C

Ic : Current of phase C

THD : Total harmonic distortion

PF : Power factor

MWh : milliwatt hour

VAR : The unit of reactive power

KVARh : kilovar hour

Std. : Standard

Avg. : Average

***BrainChild***

**Brainchild Electronic Co., Ltd.**

No. 209, Chung Yang Road, Nan Kang Dist., Taipei, Taiwan

Tel: 886-2-27861299 Fax: 886-2-27861395 E-mail: [sales@brainchild.com.tw](mailto:sales@brainchild.com.tw)

Website: <http://www.brainchild.com.tw>